MÖLLER-CHEMIE STEINPFLEGEMITTEL GmbH ZIEGELTALSTRASSE 2 D-93346 IHRLERSTEIN TELEFON 09441-176940 TELEFAX 09441-1769499 www.moellerstonecare.eu info@moellerstonecare.eu



MOELLER STONE CARE

COTTO - TERRACOTTA

TI-4.1

untreated –

Care instruction tested

CONDITIONS

When treating a newly laid surface ensure sufficient drying time for the moisture to escape from the surface and substructure (maximum 2-4% residual moisture content)

Allow 2-3 weeks drying time for an adhesive bed and 4-6 weeks for mortar bed.

Drying times are indicative only and are subject to variation depending on the weather and the object and can be longer.

It's essential that any under-floor heating has been switched off and the surface is at a normal temperature, adequately cleaned, free of stains, dry and absorbent.

Always test in an inconspicuous place to determine suitability and coverage. Always read the labels carefully. Ensure the area around the surface to be treated is well ventilated.

HELP FOR GRO	UTING
--------------	-------

Before grouting:	5245	Joint Protector - water based	Coverage:	approx.	10-15 m²/litre
CLEANING					
Construction dirt: Cementary residue and	R157	Ceramic Tile Intensive Cleaner	Coverage:	approx.	10-80 m²/litre
efflorescence: Stains:	R165 Refer t	Terracotta Cleaner o Technical Information Sheet No. 1	Coverage:	approx.	10-40 m²/litre

After cleaning the surface must be allowed to dry for at least 1 to 2 days to a residual moisture content of 2-4% before any further treatment can take place.

PROTECTION – inside

Basic protection: S232	Stain Protection - water based	Coverage: approx. 5-20 m²/litre
------------------------	--------------------------------	---------------------------------

after drying (minimum 24 hours) do the finishing

Finishing natural:

P328 Terracotta Wax - natural
Coverage: approx. 5-10 m²/litre
Finishing brown:

P329 Terracotta Wax - brown
Coverage: approx. 5-10 m²/litre

Once dry the residual material is not harmful to health.

PROTECTION – outside

Protection: S232W Stain Protection - water based Coverage: approx. 5-20 m²/litre

Once dry the residual material is not harmful to health.

MAINTENANCE - inside and outside

Regular maintenance: P324 Liquid Stone Soap - no rinse (natural product)

add approx. 25-50 ml for every 10 liters of wash water

Strong loaded surfaces: P326 Terracotta Care

-only for inside- add approx. 100-200 ml for every 10 liters of wash water,

that means five times using P324, than one time using P326.

Periodical intensive cleaning: R157 Ceramic Tile Intensive Cleaner

periodical if necessary do a cleaning with soft brush

OLD SURFACES

Films of maintenance

products and dirt:R157Ceramic Tile Intensive CleanerCoverage:approx.10-80 m²/litreLayer of Waxes:R154Stripper - Stain RemoverCoverage:approx.5-10 m²/litre

For optimum results and durability of further applications, older surfaces should be thoroughly cleaned. Repeat cleaning if necessary. After necessary drying time is allowed, proceed with products indicated under "PROTECTION". Always follow individual product directions.

ENVIRONMENT

All specialist products comply with the German Detergent Act and are registered with the Federal Environmental Offices in Berlin.

Our specialized products have been recommended for decades by leading cotto and terracotta producers.

This technical instruction card is for advice only and is supplied without obligation. We require that the person making the application adapts all data concerning the application of the products to local conditions and the materials to be cleaned. We reserve the right to make changes to our products without warning as a result of technological advancement. The person conducting the application is responsible for any third person liabilities and ensuring compliance with any local laws or regu-

Your local dealer:

All products are available from many reputable natural stone and tile dealers.

© MOELLER STONE CARE GB-01.13