MÖLLER-CHEMIE STEINPFLEGEMITTEL GmbH ZIEGELTALSTRASSE 2 D-93346 IHRLERSTEIN TELEFON 09441-176940 TELEFAX 09441-1769499 www.moellerstonecare.eu info@moellerstonecare.eu



TI-12.1

MOELLER STONE CARE

SLATE

– cleaning and maintenance –

Care instruction tested to DIN 18332 (EN 12440)

CONDITIONS

When treating a newly laid surface ensure sufficient drying time for the moisture to escape from the surface and substructure (maximum 2-4% residual moisture content).

Allow 2-3 weeks drying time for an adhesive bed and 4-6 weeks for mortar bed.

Drying times are indicative only and are subject to variation depending on the weather and the object and can be longer.

Refer to Technical Information Sheet No. 1

It's essential that any under-floor heating has been switched off and the surface is at a normal temperature, adequately cleaned, free of stains, dry and absorbent.

Always test in an inconspicuous place to determine suitability and coverage. Always read the labels carefully. Ensure the area around the surface to be treated is well ventilated.

CLEANING

Construction dirt:	R155	Intensive Cleaner - acid free
Cement smears:	R183	Cement Film Remover for Natural Stone
		only very strong thinned and short influence
		please test if surface is acid resistance

Coverage: approx. 10-80 m²/litre Coverage: approx. 5-30 m²/litre

Stains:

After cleaning the surface must be allowed to dry for at least 1 to 2 days to a residual moisture content of 2-4% before any further treatment can take place.

PROTECTION			
Without enhancing colour:	S232 Stain Protection - water based (inside and outside)	Coverage: approx.	5-20 m²/litre
Minimal colour enhancing:	S234 Stain Protection - extra (inside and outside)	Coverage: approx.	5-20 m ² /litre
Strong colour enhancing:	S244 Colour Enhancer - extra (inside and outside)	Coverage: approx.	5-20 m ² /litre
Colour enhancing satin finish:	S237* Stone Sealer - satin finish (only for inside)	Coverage: approx.	5-10 m ² /litre
-	* only on rough surfaces		
• • • • • • • • • •			

Once dry the residual material is not harmful to health. Therefore impregnators can be used on kitchen tops.

MAINTENANCE – inside and outside				
Regular maintenance:	P324	Liquid Stone Soap - no rinse (natural product) add approx. 25-50 ml for every 10 liters of wash water		
Strong loaded surfaces: -only for inside-	P323	Polish-Preserver - no rinse add approx. 100-200 ml for every 10 liters of wash water, that means five times using P324, than one time using P323.		
Periodical intensive cleaning:	R155	Intensive Cleaner - acid free periodical if necessary do a cleaning with soft brush		
OLD SURFACES				

 Films of maintenance
 products and dirt:
 R155
 Intensive Cleaner - acid free Coverage: approx.
 10-80 m²/litre

 Layer of Waxes:
 R154
 Stripper - Stain Remover
 Coverage: approx.
 5-10 m²/litre

 For optimum results and durability of further applications, older surfaces should be thoroughly cleaned. Repeat cleaning if necessary. After necessary drying time is allowed, products indicated under "PROTECTION". Always follow individual product directions.

ENVIRONMENT

All specialist products comply with the German Detergent Act and are registered with the Federal Environmental Offices in Berlin.

Our specialized products have been recommended for decades by leading natural stone producers.

This technical instruction card is for advice only and is supplied without obligation. We require that the person making the application adapts all data concerning the application of the products to local conditions and the materials to be cleaned. We reserve the right to make changes to our products without warning as a result of technological advancement. The person conducting the application is responsible for any third person liabilities and ensuring compliance with any local laws or regu-

All products are available from many reputable natural stone and tile dealers.

or any third person liabilities and ensuring compliance with any local laws of regu-	
Your local dealer:	